

Installation Guide

Service and Warranty

If your product is to be returned to Seon Design for service, please call toll free 877-630-7366, or 604-524-6437 and ask for a Return Authorization (RA) number. An RA number allows the Service Technicians to better track your product when it comes in for service. Please show the RA number on the outside of the package. ANY PRODUCT SENT TO SEON DESIGN WITHOUT AN RA NUMBER MAY BE REFUSED.

Please refer to the Warranty form provided with your product to review the terms of warranty service, contact and shipping information, as well as other important issues regarding the service and operation of your product.

© 2003 Seon Design Inc.
All rights reserved.
Document Part Number: 700-0015-01

1 Features

On certain buses, intermittent transient voltage surges have been found that have the potential to damage the input circuitry of **The Scout VCR**. **The Scout Ignition Trigger Module** prevents these transients from causing any damage to the circuitry.

2 Installation

- 1 The module can be inserted at any point in the yellow ignition trigger wire of **The Scout System**. At a convenient location, cut the yellow wire and strip both ends approximately 1/4".
- 2 Crimp the butt-splice connectors on **The Scout Ignition Trigger Module** the stripped ends of the yellow ignition wire.
- 3 Perform a light 'pull-test' on the crimped connections to ensure a strong connection.
- 4 Test the system by turning on the vehicle ignition. If the 'Delay-On' feature is being used, the VCR will power up after the initial 'Delay-On' period.
- 5 Please contact **Seon Design** if there are any problems encountered with the installation of this module.

Crimp Onto Stripped Ends Of Ignition Wire

