

# Remote Power Indicator for Trooper and Explorer DVR Systems

## Quick Installation Sheet

Document part number: 700-0060 R001

### Introduction

The remote power indicator is mounted in a vehicle panel and illuminates when the cameras are powered on. This *Quick Installation Sheet* describes how to install the remote power indicator with an existing Trooper or Explorer DVR System. The remote power indicator is supplied with a 20 ft (6.1 m) cable and 2.1 mm connector that connects to the POWER or AUX POWER connector on the DVR back panel.

In order to access the DVR back panel, the lock box key is required to unlock the door of the lock box. For complete information, see the *Installation and User's Guide* for your DVR system.

### Installing the Remote Power Indicator

Suggested tool include a power drill with a 1/2" drill bit.

#### To install the remote power indicator:

1. Turn off all power to the DVR.
2. Drill a 1/2" hole in the desired location. Ensure that the area behind the hole is clear of obstructions before drilling.
3. Feed the connector and cable through the mounting hole. Secure the remote power indicator into position.
4. Route the connector end of the cable to the location of the DVR.
5. Unlock the lock box door and slide the DVR out of the lock box.
6. Connect the 2.1mm connector to the appropriate power connector (POWER1 or POWER2, or PWR1 or PWR2 on the Explorer DVR; AUX POWER on the Trooper DVR.)
7. Slide the DVR into the lock box and secure the lock box door.




Figure 1: Remote Power Indicator

Seon Design is a registered trademark of Seon Design Inc.  
© February 2008 Seon Design Inc. All rights reserved.  
Document part number: 700-0060 R001 Printed in Canada

Quick Installation Sheet: *Remote Power Indicator for Trooper and Explorer DVR Systems*

**SEON DESIGN INC.:**

(a) MAKES NO REPRESENTATION, WARRANTY, GUARANTEE OR COVENANT, EXPRESS OR IMPLIED, AS TO THE ACCURACY, SUFFICIENCY OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN THIS USER MANUAL OR ANY OTHER USER OR OTHER MANUAL OR OTHER DOCUMENTATION PROVIDED BY SEON DESIGN INC. WITH RESPECT TO THE PRODUCT(S) DESCRIBED HEREIN, INCLUDING WITHOUT LIMITATION ANY DESCRIPTION OF GOODS OR SERVICES, SPECIFICATIONS, MODELS, DRAWINGS, OR DIAGRAMS.

(b) DOES NOT ASSUME AND SHALL NOT BE SUBJECT TO AND DISCLAIMS ANY AND ALL RESPONSIBILITY AND OR/LIABILITY FOR LOSSES, DAMAGES, COSTS OR EXPENSES ARISING OUT OF BREACH OF CONTRACT OR OF WARRANTY, TORT (INCLUDING NEGLIGENCE AND STRICT LIABILITY) OR OTHERWISE, WHETHER SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, SPECIAL OR CONTINGENT, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK; AND

(c) EXPRESSLY DISCLOSES THAT IF THIS MANUAL IS WRITTEN IN ANY LANGUAGE OTHER THAN ENGLISH, THAT ALTHOUGH SEON DESIGN INC. HAS USED REASONABLE CARE TO MAINTAIN THE ACCURACY OF THE TRANSLATION FROM THE ENGLISH LANGUAGE, THE ACCURACY OF SUCH TRANSLATION IS NOT GUARANTEED OR WARRANTED BY SEON DESIGN INC. PLEASE REFER TO THE ENGLISH LANGUAGE VERSION OF THIS USER MANUAL FOR APPROVED SEON CONTENT. THE ENGLISH LANGUAGE VERSION IS AVAILABLE UPON REQUEST FROM THE SEON CUSTOMER SERVICE DEPARTMENT.

**Contact information:**

Seon Design Inc.  
Unit 111, 3B Burbidge Street  
Coquitlam, BC  
Canada V3K 7B2

**Toll Free Phone:** 1-877-630-7366  
**Phone:** 1-604-941-0880  
**Toll Free Fax:** 1-866-664-3677  
**Fax:** 1-604-941-0870  
**Email:** [sales@seon.com](mailto:sales@seon.com)  
**Web:** [www.seon.com](http://www.seon.com)